

Corinex

AV200 Powerline Ethernet Wall Mount



Declaration of Conformity



Model: **Corinex AV200 Powerline Ethernet Wall Mount**

Manufacturer: **Corinex Communications Corp.
670-789 West Pender Street
Vancouver, BC
Canada V6C 1H2**

Directives which Conformity is Declared:

**EMC: 89/336/EEC
LVD: 73/23/EEC
R&TTE: 1999/5/EEC**

Standards which Conformity is Declared:

**EN 55022
EN 55024
EN 60950
EN 61000-3-2
EN 61000-3-3**

The undersigned hereby declares the above specified equipment conforms to the above directives and standards.

Printed name / Title: **Peter Sobotka / CEO**

Place / Date: **Vancouver / March.21.2006**

Signature: 

This document, as well as the software described in it, is furnished under license and may be used or copied only in accordance with the terms of the license. The content of this document is furnished for informational use only, it is subject to change without notice, and it does not represent a commitment on the part of Corinex Communications Corp.

Corinex Communications Corp. assumes no responsibility or liability for any errors or inaccuracies that may appear in this document.

It is our policy to enhance our products as new technologies, hardware components, software and firmware become available; therefore, the information contained in this document is subject to change without notice.

Some features, functions, and operations described in this document may not be included and sold in certain countries due to government regulations or marketing policies.

The use of the product or its features described in this document may be restricted or regulated by law in some countries. If you are unsure which restrictions or regulations apply, you should consult your regional Corinex office or the authorized reseller.

Published by:

Corinex Communications Corp.
#670-789 West Pender Street
Vancouver, B.C.
Canada V6C 1H2
Tel.: +1 604 692 0520
Fax: +1 604 694 0061

Corinex is a registered trademark of Corinex Communications Corp.

Microsoft, MS-DOS, MS, Windows are either registered trademarks or trademarks of Microsoft Corporation in the U.S.A. and/or other countries.

All products or company names mentioned herein may be the trademarks of their respective owners.

Copyright (c) 2001-2006 by Corinex Communications Corp.

NOTE: This equipment has been tested and found to comply with the limits for Class B information technology equipment. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference, the end user is advised to take adequate measures.

CORINEX COMMUNICATIONS CORPORATION

This End User License Agreement (“EULA”) is a legal agreement between you and CORINEX COMMUNICATIONS CORPORATION (“CORINEX”) with regard to the copyrighted Software provided with this EULA.

Use of any software and related documentation (“Software”) provided with a CORINEX hardware product, or made available to you by CORINEX via download or otherwise, in whatever form or media, will constitute your acceptance of these terms, unless separate terms are provided by the software supplier, in which case certain additional or different terms may apply. If you do not agree with the terms of this EULA, do not download, install, copy or use the Software.

1. License Grant. CORINEX grants to you a personal, non-transferable and non-exclusive right to use the copy of the Software provided with this EULA. You agree you will not copy the Software except as necessary to use it on a single hardware product system. You agree that you may not copy the written materials accompanying the Software. Modifying, translating, renting, copying, transferring or assigning all or part of the Software, or any rights granted hereunder, to any other persons, and removing any proprietary notices, labels or marks from the Software is strictly prohibited. Furthermore, you hereby agree not to create derivative works based on the Software. You may permanently transfer all of your rights under this EULA, provided you retain no copies, you transfer all of the Software, and the recipient agrees to the terms of this EULA. If the Software is an upgrade, any transfer must include all prior versions of the Software.
2. Copyright. The Software is licensed, not sold. You acknowledge that no title to the intellectual property in the Software is transferred to you. You further acknowledge that title and full ownership rights to the Software will remain the exclusive property of Corinex Communications Corporation and/or its suppliers, and you will not acquire any rights to the Software, except as expressly set forth above. All copies of the Software will contain the same proprietary notices as contained in or on the Software.
3. Reverse Engineering. You agree that you will not attempt, and if you are a corporation, you will use your best efforts to prevent your employees and contractors from attempting to reverse compile, modify, translate or disassemble the Software in whole or in part. Any failure to comply with the above or any other terms and conditions contained herein will result in the automatic termination of this license and the reversion of the rights granted hereunder to CORINEX.
4. Disclaimer of Warranty. The Software is provided “AS IS” without warranty of any kind. CORINEX and its suppliers disclaim and make no express or implied warranties and specifically disclaim warranties of merchantability, fitness for a particular purpose and non-infringement of third-party rights. The entire risk as to the quality and performance of the Software is with you. Neither CORINEX nor its suppliers warrant that the functions contained in the Software will meet your requirements or that the operation of the Software will be uninterrupted or error-free.
5. Limitation of Liability. Corinex’s entire liability and your exclusive remedy under this EULA shall not exceed the price paid for the Software, if any. In no event shall CORINEX or its suppliers be liable to you for any consequential, special, incidental or indirect damages of any kind arising out of the use or inability to use the software, even if CORINEX or its supplier has been advised of the possibility of such damages, or any claim by a third party.
6. Applicable Laws. This EULA will be governed by the laws of Canada, excluding its conflict of law provisions.

7. Export Laws. This EULA involves products and/or technical data that may be controlled under any applicable export control laws, and regulation, and may be subject to any approval required under such laws and regulations.
8. Precedence. Except as set out above, where separate terms are provided by the software supplier, then, subject to this EULA, those terms also apply and prevail, to the extent of any inconsistency with this EULA.

Contents

Copyright	1
End User License Agreement	2
1. Introduction	5
1.1 Overview	5
1.2 About this manual	5
2. Installation Guide	6
2.1 What this Package Contains	6
2.2 System Requirements	6
2.3 Physical Description	6
2.4 Technical specification	8
2.5 Installing the AV200 Powerline Ethernet Wall Mount	8
2.6 Basic Testing of the TCP/IP Setup and AV200 Network	8
3. Web Configuration	9
3.1 Authentication Page	9
3.2 Main Page	10
3.3 Additional Information Page.....	11
3.4 Change Configuration Page	14
3.5 Firmware Update Page	27
4. In-Home AV Network Topology	28
4.1 Introduction	28
4.2 Network Scenarios	28
5. Network Configuration	32
5.1 Setting an IP Address in your computer	32
5.2 Improving Network Performance	38
5.3 Checking Network Performance	39
5.4 Using PLC Filtres	39
6. Troubleshooting Guide	41

1 Introduction

1.1 Overview

The *Corinex AV200 Powerline Ethernet Wall Mount* is a network interface adapter which uses the electric power lines already in your home or office as a medium for communication. After successful installation, the AV200 Powerline network behaves like a traditional LAN for computers. The *Corinex AV200 Powerline Ethernet Wall Mount* supports up to 200 Mbps network speed.

The advantage of our product is that it keeps network maintenance costs low and eliminates usage barriers, while requiring no additional wiring. It is highly integrated, and requires no external electronic components.

The *Corinex AV200 Powerline Ethernet Wall Mount*:

- Enables users to connect individual PCs or other devices with Ethernet communications links into a local area network through existing electric power lines (Powerline)
- Enables PC file and application sharing
- Enables peripheral and printer sharing through the Powerline network
- Enables shared broadband Internet access
- Enables sharing of bandwidth for multimedia payloads, including voice, data, audio and video
- Eliminates the need for long network cables throughout your home or office
- A real, cost-effective, and reliable solution for high-speed communications in any home or small office

1.2 About this Manual

This User Guide includes everything you need to know to help you successfully install the *Corinex AV200 Powerline Ethernet Wall Mount* and meet your networking needs. With the information in this manual, you should be able to:

- Analyze your network efficiency
- Plan the configuration of your *Corinex AV200 Powerline Ethernet Wall Mount*
- Install and configure your *Corinex AV200 Powerline Ethernet Wall Mount* according to your plan
- Verify and optimize the performance of your *Corinex AV200 Powerline Ethernet Wall Mount*

2 Installation Guide

2.1 What this Package Contains

When you receive your *Corinex AV200 Powerline Ethernet Wall Mount*, check to be sure that your package contains:

- *Corinex AV200 Powerline Ethernet Wall Mount*
- Straight-forward Ethernet cable
- Printed Quick Start Guide
- CD with documentation

We are constantly innovating our products. For the latest hardware/software changes, downloads, and additional information on your device, please visit www.corinex.com.

We also advise you to visit our Corinex Authorized Powerline Partners Program web page <http://capp.corinex.com/>, where you can find valuable information about complex applications and installations, as well as partners in your area who can provide installation services.


2.2 System Requirements

- IBM compatible PC or a Macintosh
- One available 10/100 Mbps Ethernet port
- Windows 98/ME/2000/NT/XP, Mac OS X or Linux operating system
- Javascript compatible web browser for configuration (Netscape, Internet Explorer, Opera...)

2.3 Physical Description



LED Definitions

(LEDs from top to bottom)



- 1. POWER** Green On: Power on
Off: Power off
- 2. PLC** Green On: Powerline activity
Off : No Powerline activity
Blinking : Receiving/Transmitting data
- 3. ETHERNET** Green On: Link on LAN
Off: No link on LAN
Blinking: receiving/transmitting data

Connector Definitions



2.4 Technical Specifications

1. LAN: 1x RJ-45 LAN 10/100 Ethernet port

Standards Compliance	IEEE 802.3u
Speed	Up to 200 Mbps on physical layer
AC Plug Type	US, EU, UK and AUS
LED Status Lights	Power, PLC Link/Activity, Ethernet Link
Interface	10/100BaseT Fast Ethernet, Powerline
Frequency Range used	2 – 34 MHz
Power Input	85 to 265 V AC, 50/60 Hz
Dimensions	148 mm L x 106 mm W x 47 mm H
Transmitted Power spectral density	-56 dBm/Hz
Power Consumption	5W
Safety & EMI	UL/EN 60950, FCC Part 15, EN 55022 EMC limits

2.5 Installing the AV200 Powerline Ethernet Wall Mount

To connect the *Corinex AV200 Powerline Ethernet Wall Mount* to your computer, follow the steps listed below.

1. Connect the supplied Ethernet cable to the LAN port on the wall mount and to an Ethernet port on your computer.
2. Connect the *Corinex AV200 Powerline Ethernet Wall Mount* unit directly to any AC electrical outlet, not to a power strip..

Note: Please use a straight-forward Ethernet cable for connection of the AV200 Powerline Ethernet Wall Mount to your computer. If you are connecting the AV200 Powerline Ethernet Wall Mount to a modem or switch, please use a crossover cable.

2.6 Basic Testing of the TCP/IP Setup and AV200 Network

To verify that your equipment is connected and working correctly, use the standard **Ping** utility. In Windows, click on menu **Start -> Run**, then write the command **ping IPADDRESS -t**, where IPADDRESS is the IP address of the computer to which the AV200 Powerline Ethernet Wall Mount is connected, e.g. **ping 192.168.4.1 -t** (this process can be interrupted by pressing **CTRL+C**).

1. Ping the IP address of the computer to which the AV200 Powerline Ethernet Wall Mount is connected. If this fails, there is a problem with the Ethernet network card or with the TCP/IP protocol.
2. Repeat the same process with the other computers on your AV200 Powerline network.
3. If all the computers can ping themselves, try pinging another computer on your AV200 Powerline network. If this fails, then there is a problem with the connection across your AV200 Powerline network or with the configuration of the AV200 Powerline Ethernet Wall Mounts. Check the connection to the outlet, or try a different outlet. Verify the configuration of the AV200 Powerline Ethernet Wall Mounts, especially the network number, as only adapters in the same network can see each other. Please see chapter 3 for details on configuration.

If you experience any problems with your setup, try unplugging the AV200 Powerline Ethernet Wall Mount and restarting the computer, as this sometimes fixes the problem. If the problem persists, please refer to the troubleshooting guide at the end of this manual.

3 Web Configuration

In order to access the web configuration pages, it is necessary to know the adapter's IP address and to be connected to it (e.g. through an Ethernet cable). Adapters that have not previously been configured have the IP address 10.10.1.69. Open a web browser (Microsoft Internet Explorer v6.0, Mozilla v1.7.2 and Mozilla Firefox v1.0 have been verified for use with these products.), and type the IP address in the address bar – the URL should be <http://10.10.1.69/> unless you are not setting it up for the first time, and you have previously changed it to something else.


Changing the default IP address, 10.10.1.69, is required to allow access to an adapter when two or more units are active on the same network. The IP address is a device's unique identifier on a network, so the adapters would not be able to tell each other apart if they had the same identity, just as a postman wouldn't know which house to deliver to, if two neighbors in a large city had the same street number. Follow the steps below to configure a new IP address for each adapter:

1. In your computer's network settings, enter an address in the range 10.10.X.X and the netmask 255.255.0.0. This is necessary in order to be compatible with the adapter's default settings. For details on how to set up an IP address in your computer, please see chapter 5.
2. Plug in your AV200 Powerline Ethernet Wall Mount and connect it to the PC via supplied Ethernet cable.
3. Open the Web browser and type the following URL: http://10.10.1.69. You will get to the configuration web interface of the AV200 Powerline Ethernet Wall Mount.

3.1 Authentication Page

If the configuration password is enabled, you'll need to login before you can access the configuration web pages for making changes to the network. Therefore, you will first be taken to the **Authentication** page, where you will need to enter the password. The embedded web server has an authentication timeout of 5 minutes; i.e. if no web pages are loaded within 5 minutes, the login expires and you will need to login again.

Note: The default password is “**paterna**”.



Note: If password protection is disabled, you will be taken straight to the Main page, rather than the Authentication page.

3.2 Main Page

This is the first page after login, or simply the first page, if the configuration password is disabled. It shows basic status information about the adapter, a list of available Powerline connections, MAC and IP addresses, MAC type, etc.

AV200 Powerline Ethernet Adapter

Status | Additional Information | Basic Settings | Advanced Settings

General Information

MAC Type	In Home AV Node Type	AV
MAC Address	00:0C:29:00:00:00	00:0C:29:00:00:00
IP Address	10.0.0.29	Number of Bores
SN	-	MACID
AGC RX	Enabled	WAG
Wake S	Disabled	Xu
Access Protocol	NONE	

Available Connections

PoE Connections:

PoE Port	MAC Address	Phy Tx Throughput	Phy Rx Throughput	Bridge State	Network ID
Empty table					

External Interfaces:

Interface	Phy Throughput	Bridge State
eth0	1.0 Mbps	Forwarding

At the top of the screen are the main categories, „Status“, „Additional Information“, „Basic Settings“ and „Advanced Settings“. The menu shows your current position in the web interface. (The category is a different color and not clickable.)

3.3 Additional Information Page

This page shows more detailed information about the modem.

System Information	
Uptime	Shows how long the modem has been running since the last reboot.
Firmware Version	Shows the detailed firmware version.

MAC Status	
MAC Address	Displays the unique MAC address of the AV200 Powerline modem.
MAC Type	MAC Type – in Spirit it is Inhome AV.
Node Type	Shows the type of node – this can be EP (Slave), AP (Master) or Static AP (Static Master).
Network Identifier	Shows the Network Identifier string. Only devices with the same Network Identifier can communicate with each other.
Encryption Key	Shows whether the communication encryption is enabled or not.

Network Status	
IP Configuration	Shows „ Fixed “ for a static IP setup or „ DHCP “ if the device is configured as a DHCP client.
IP Address	Shows the current IP Address of the modem.
Subnet Mask	Shows the subnet mask.
Default Gateway IP Address	Shows the Default Gateway.

PHY Status	
Notches	Indicates whether or not frequency notches are enabled. In the European Union, notches should be always enabled, in order to eliminate interference with Radio Amateur bands specified by the IARU (International Amateur Radio Union).
Power Control	Indicates status of the power control mechanism (described in chapter 3.4.4).

Multicast Status	
IGMP Aware Multicast Syndication	Shows status of the support for IGMP protocols (described in chapter 3.4.5).
Multicast Bindings	Shows all multicast bindings between multicast IP Addresses and AV200 Powerline MAC addresses.

12

VLAN Status	
VLAN Configuration	Indicates whether or not VLAN is enabled.
VLAN Tag	Shows the selected VLAN Tag. All traffic from the ethernet port is tagged with this tag.
VLAN Priority	Shows the selected priority which is inserted into the VLAN tag.

Priority Status	
Default Priority	Shows the default priority for traffic transmission.
Criterion 1 & 2	Shows which criterion is used to classify traffic. This can be TOS, 802.Ip or Custom . If Custom, the full criterion parameters are displayed below. Please see chapter 3.4.7 for additional information.

Security Status	
Status	Indicates whether or not the web interface is password protected.

3.4 Change Configuration Page

3.4.1 Overview

The configuration pages allow you to change the settings on the wall mount. Any parameter changed here will be stored in the wall mount's permanent memory, and loaded and configured automatically after the next system boot. Any changes will take effect immediately after bootup, with the exception of Network Configuration settings (these require a reset of the wall mount).

The configuration is divided into two sections: „**Basic settings**“ and „**Advanced settings**“.

Corinex AV200 Powerline Ethernet Adapter Web Configuration

MAC Configuration

•MAC Type

In-Home AV Configuration:

•Node Type

•Network Identifier

•Encryption Key

[Return to main page](#)

Network Configuration*

•IP Configuration

Fixed IP Configuration:

•IP Address

•Subnet Mask

•Default Gateway IP Address

*All changes in *Network Configuration* will have effect after system boot

14

Notes :


- A different IP must be set for each adapter within a single network. An adapter's IP does not need to be in the same range as the PCs communicating with the adapters, but to access the configuration page, a PC must have the same address range as the adapter (10.10.X.X and netmask 255.255.0.0 in the default state).
- The adapter's netmask can also be changed, for example to a type C (255.255.255.0) if necessary. This is a more advanced option, which you may ignore if you're not familiar with it.

- If the wall mount will be accessed through a router (for example in a large office network), the gateway IP needs to be configured. Otherwise, it can be ignored.

CHANGING AN ADAPTER'S IP TAKES EFFECT ONLY AFTER A RESTART OR REBOOT. YOU MAY WANT TO PLACE A LABEL ON EACH ADAPTER WITH ITS IP ADDRESS, SO YOU DON'T ACCIDENTALLY LOSE THE ABILITY TO ACCESS IT.

3.4.2 Basic Settings

In many cases, the only thing that needs to be changed is the Network Identifier and/or Encryption in order to avoid interfering with other networks and protect the data being transmitted. Many users will not need to enter the Advanced settings section to ensure total security of their Powerline network.



15

The AV200 technology supports multiple networks on a single electrical circuit. The networks are differentiated by Network Identifiers, which can be set in this section. The Network Identifier is a character string (Network Identifier field) which simply acts as a name for the network. It must be the same value for all adapters on the same network. Adapters with different Network Identifiers are not able to communicate with each other.

The Network Identifier string can have up to 20 ASCII characters. Quote and double-quote characters are not supported. Extended ASCII characters are not recommended.

If you want to enable 3DES encryption in your network, please select one of the input methods and enter the password.

Input methods:

ASCII	If ASCII is selected, the Encryption Key string can have up to 24 non-extended ASCII characters. Quote and double-quote characters are not supported. Extended ASCII characters are not supported.
HEX	On the other hand, if HEX mode is selected, the Encryption Key string can have up to 42 hexadecimal digits (for example 34AE4F54B38D). HEX strings generate more secure keys.

3.4.3 Advanced Configuration

The advanced configuration section of the web interface is divided into several subsections, which are described here.

3.4.3.1 MAC Configuration

The following parameters relate to the network topology. The current firmware version (Spirit 2.0.21 at the time of this publication) supports only one topology: In-Home AV. In this In-Home AV topology, two different node types can be configured, setting a node to function as either an **Automatic EP/AP** (End Point or Access Point, depending on the other nodes in the network) or a **Fixed AP** (assigned Access Point). Section 4 (In-Home AV Network Topology) contains more information about the available network topologies.

MAC Configuration

•MAC Type In-Home AV ▾

In-Home AV Configuration:

•Node Type EP ▾

•Network Identifier

•Encryption Key

If you want to configure the wall mount to function as an automatic EP/AP, please select „**EP**“ from the list. If you want the wall mount to behave as a Master, select „**Fixed AP**“ from the list. In either case, click „**OK**“ to confirm your selection.

Note: Fixed AP is available only when the wall mount is configured with a non-empty Network Identifier (please read below for details on Network Identifiers).


The AV200 technology supports multiple networks on a single electrical circuit. The networks are differentiated by Network Identifiers, which can be set in the MAC section. The Network Identifier is a character string (Network Identifier field) which simply acts as a name for the network. It must be the same value for all wall mounts on the same network. Wall mounts with different Network Identifiers are not able to communicate with each other.

Note: Please refer to section 4.2 for more information about the network types and their Network Identifiers.

If the Network Identifier field is left blank, the default, publicly available network is configured, and the adapter can communicate with all other adapters with empty Network Identifier fields. When you enter a Network ID, a private network is configured.

Note: The Network Identifier string can have up to 20 ASCII characters. Quote and double-quote characters are not supported. Extended ASCII characters are not recommended

The following picture shows an example of two AV200 networks with different Network Identifiers:



Data transmission between adapters (called modems in the picture) is encrypted with a Triple-DES algorithm. The Encryption Key can be configured from a character string (Encryption Key field, ASCII or HEX), which is actually a passphrase. The three 56-bit keys for Triple-DES encryption are obtained from this passphrase by means of a hash function. Entering a null string (leaving it blank) disables the encryption. After selecting the input method and entering a passphrase, click „OK“ to confirm your choice.

Note: The encryption will be enabled only if a non-empty Network Identifier is set.

Note: If **ASCII** is selected, the Encryption Key string can have up to 24 non-extended ASCII characters. Quote and double-quote characters are not supported. Extended ASCII characters are not supported. On the other hand, if **HEX** mode is selected, the Encryption Key string can have up to 42 hexadecimal digits (for example 34AE4F54B38D). HEX strings generate more secure keys.

3.4.3.2 Network Configuration

Your Corinex AV200 Powerline Wall mount can be configured to use either DHCP (automatic IP address assignment), or a fixed IP.

The following parameters are used by the fixed IP configuration. In order to use the wall mount in conjunction with other equipment within an In-Home AV network, it is necessary to define a valid IP address unique to the network, as well as a proper subnet mask and gateway address. These parameters will be stored in the wall mount and implemented following the next system boot.

Network Configuration*

•IP Configuration Fixed ▾

Fixed IP Configuration:

•IP Address

•Subnet Mask

•Default Gateway IP Address

*All changes in *Network Configuration* will have effect after system boot

After changing any of these parameters, click **OK** to save your changes.

Note: Any change in the Network Settings requires a reboot of the wall mount to take effect.

Note: If you forget the IP address of the device, please recover it with the utility „getIP,“ which is located on the Documentation CD, or download it from the Corinex website at www.corinex.com.

3.4.4 PHY Configuration

By default, the wall mounts transmit over a frequency range anywhere from 2 to 32 MHz, and when an access network is detected, the wall mounts transmit over a range from 13.3 to 33.3 MHz, in order to operate without interfering with each other. This mode change is done automatically and cannot be configured by the user. It is only possible to enable or disable this „notches“ function. The notches pre-defined in the wall mount correspond to the IARU (International Amateur Radio Union) band plan for each world region. If the wall mount is running in an environment where it can cause interference to a HAM radio receiver, it is recommended to enable notches, in order to block the Powerline signal from the frequency bands used by radio amateurs.

PHY Configuration

•Notches Disabled ▾

•Power Control Enabled ▾

Note: The user is strongly advised to turn on the notching function.

Power Control is an automatic transmission power control which isolates networks with different network IDs.

Power Control is turned on only if there are other networks present in the channel. If the transmission strength reaches the isolation point between networks, the transmission power remains at a low level. But if the isolation point is not reached, the nodes resume transmitting at their original levels.

3.4.5 Multicast Configuration

In order to optimize multicast traffic (video streams, etc.) between AV200 Powerline wall mounts, you can specify which wall mounts you want to receive the traffic. Others will then not be able to receive the multicast communication, and therefore the bandwidth will be used only for transmission to the intended recipients, making your broadcast, and overall network, more efficient.

This form shows the list of multicast bindings, where multicast IP addresses are assigned to a unicast (stream source) MAC address. This list can be saved to the wall mount (**Save in NVRAM**). Moreover, you can remove bindings by checking their Remove checkboxes and clicking „**OK**“. Add a new binding to the list by entering the multicast IP address, in decimal format (ddd.ddd.ddd.ddd), and the unicast MAC address, in hexadecimal format (XXXXXXXXXXXX), in the appropriate fields and clicking „**OK**“.

The new IGMP Aware Multicast Syndication feature included in Spirit 2.0 can be enabled via this form. This feature is only available on private networks (with a valid Network Identifier) and End Points (EP).

Multicast Configuration

•IGMP Aware Multicast Syndication: Disabled ▾

Multicast IP Address	Unicast MAC Address	Remove
<i>Empty list</i>		

New Binding:

•Multicast IP Address

•Unicast MAC Address (hex)

3.4.6 VLAN Configuration

When AV200 Powerline wall mounts are used for ADSL extension, it is important for the operator to be able to distinguish the type of traffic that each wall mount is generating. This is usually done by means of VLAN tagging. The AV200 technology includes the ability to tag all traffic that enters the Powerline network through each adapter's Ethernet interface. It is only tagging - there is no VLAN filtering on an AV200 Powerline network.

The parameters for VLAN configuration can be set in the form displayed below. First, the Spirit VLAN can be enabled or disabled (**Spirit VLAN Configuration** checkbox). If enabled, the VLAN tag (**Spirit VLAN Tag** field) and priority (**Spirit VLAN Priority** field) can then also be configured.

VLAN Configuration

- VLAN Configuration Disabled ▾
- VLAN Tag (2, 3, ... 4094) 0
- VLAN Priority 0 ▾

21

3.4.7 Priority Configuration

Several options are available in this form. The first, and easiest to understand and use, is the Default Priority value. Output traffic generated by adapters with higher default priority will have preference in the network. The rest of the parameters let you configure two Class of Service criteria (**Criterion 1** and **Criterion 2** checkboxes).

If you select **None**, **8021p** or **TOS**, custom parameters are hidden, leaving a pre-defined setting in place.

Priority Configuration

- Default Priority 2 ▾
- Criterion 1 None ▾
- Criterion 2 None ▾

If you select **Custom** on the other hand, custom parameters are shown as below and can then be configured.

Priority Configuration

•Default Priority: 2

•Criterion 1: Custom

Custom Criterion 1 Configuration

•Class: 0

•Pattern (hex): 002000000010000

•Bitmask (hex): 111111111

•Class Offset: 0

•Class Bitmask (hex): 111111111A:02004

•Class Pattern 1 (hex): 002000000000000

•Class Priority 1: 2

•Class Priority 2: 2

•Class Priority 3: 2

•Class Priority 4: 2

•Class Priority 5: 2

•Class Priority 6: 2


•Class Priority 7: 2

•Class Priority 8: 2

Buttons: Ok, Cancel

When several traffic flows are sharing the same network, it is sometimes necessary to establish several levels of priority in order to guarantee that bandwidth-sensitive applications such as video or telephony continue to work smoothly under network congestion.

The traffic classifier is a packet inspector that is able to recognize several patterns in an Ethernet frame, and assign a different priority to each of them. To ensure that the classification is done correctly, there is a trigger mechanism prior to the actual classification. The trigger mechanism is also based on pattern recognition of a given location in each Ethernet packet. The following picture depicts the packet classification mechanism:



There is one offset, and one bitmask and pattern for the trigger condition. The trigger condition is used to make sure that the Ethernet frame contains, for example, an IP frame. To check this condition, the offset must be set to 16 and the bitmask to 0xFFFF. If the resulting pattern is 0x0800, then the Ethernet frame contains an IP packet and the classification can be made to a known field.

There is another offset and bitmask for the classification condition. The resulting value is compared with a set of patterns. If the value matches a given pattern, the packet will be classified with the specified priority. If the value does not match any of the patterns, it will get a default priority.

There is a set of pre-defined criteria which classifies traffic based on the **802.1p** field of the Ethernet packet or the **TOS** field of the IP packet.

3.4.8 Security Configuration

The web application allows you to change the configuration password by typing a new one in the specified fields. (You must confirm your password by re-typing it in the second field.) If both fields are left empty, the configuration password will be disabled (the message '**No password installed**' will be shown in the security configuration form). Consequently, the web configuration authentication will be disabled too. The authentication can be enabled again by setting a password.

Security Configuration

Status Password is currently installed

Set Configuration Password:

- New password
- Confirm new password

Factory Reset*:

- Password

***Warning!** Current configuration will be lost

If you want to restore the adapter's default settings, you can invoke a factory reset. In order to do this, you have to enter the password „**betera**“ in the appropriate field and click **OK**. The adapter will reboot with the following configuration:

- IP address = 10.10.1.69
- Configuration interface password = paterna
- Factory reset password = betera
- Device type is Automatic EP/AP
- Network Identifier is blank
- No encryption and no VLAN settings

3.4.9 Hardware Reset

Clicking on this button will reset (or reboot) your wall mount. The configuration will remain the same, and any changes made in the Network Configuration section will be applied. This means that if you've changed the IP address, the wall mount will reboot with that new address.

Hardware Reset

3.4.10 Flash Upgrade

The firmware, the loader and the factory settings (default factory configuration) are stored in Flash memory. To upgrade them, first select the Flash section to update (**Firmware, Loader or Factory Settings**) and the protocol (**FTP or TFTP**). Then type the IP address of the FTP or TFTP server (**Server IP Address** field). In the case of FTP, type the user name (**FTP User**) and password (**FTP Password**). Then, for either FTP or TFTP, type the file name of the firmware disk image (**File Name**). Finally, click **OK**.


Flash Upgrade	
Status	Ready: initial status
•Flash Section	Firmware
•Upgrade Protocol	FTP
•Server IP Address	<input type="text"/>
•FTP User	<input type="text"/>
•FTP Password	<input type="text"/>
•Filename	<input type="text"/>
<input type="button" value="Ok"/> <input type="button" value="Cancel"/>	

3.4.11 Firmware upgrade using a TFTP Server

To upgrade the firmware of the modem using TFTP, a TFTP server must be running on a computer. We recommend a freeware tool called **TFTPD32**. This tool can be downloaded at the following address: <http://tftpd32.jounin.net/>. The firmware image is provided by Corinex.

Follow the steps below to upgrade the firmware of a modem:

1. Execute **TFTPD32**. This application has the GUI shown in the picture below:



2. Place the image file in the directory specified in **Current Directory** or change it to point to the place where the image is stored.
3. Open the Web browser and enter the IP of the modem that to be upgraded.
4. When the page comes up, click on **Change configuration**.
5. In the **Firmware Update** window, select TFTP and enter the IP of the TFTP server and the name of the image file, as shown in the next picture.


Flash Upgrade	
Status	Ready: initial status
•Flash Section	Firmware
•Upgrade Protocol	TFTP
•Server IP Address	10.10.1.23
•FTP User	
•FTP Password	
•Filename	spirit_dh10c_9001_s1_1_40_vzei
<input type="button" value="Ok"/> <input type="button" value="Cancel"/>	

6. Click **OK** to start the process. Progress information is shown on the Web page every 30 seconds.
7. The modem will first download the file and then calculate the CRC.
8. If the CRC is correct, the **Hardware Reset** button will be highlighted. The modem must be reset for the new firmware to start running.

3.4.12 Configuring Video Applications

In the case of a network where real-time traffic must coexist with massive data transfers, the service classifier must be used to prioritize the bandwidth-sensitive traffic above the other types of traffic.

As an example, consider the network shown below.



The node connected to the ADSL modem is the access point. Data and video are delivered through ADSL. The access point has to prioritize UDP video over data to avoid a jittery image when there is a heavy data download.

First of all, the **Criterion** field must be set to **Custom**, in order to create one's own rules to classify the traffic.

To prioritize UDP traffic, first the Ethernet packets containing IP packets have to be detected. This requires detecting the pattern 0x0800 at offset 16. Because the field to inspect is two bytes, the bitmask must also cover the same space. Therefore, 0xFFFF is used as bitmask. These values are introduced in the fields **Custom Criterion Offset**, **Custom Criterion Pattern** and **Custom Criterion Bitmask**.

Once the trigger condition is entered, the classification rules must be specified. Only the fields that are actually changed will take effect. The rest will be ignored. IP packets have a one-byte field at offset 27 that indicates the Protocol Type. UDP protocol is pattern 0x11. Because the field to inspect is only one byte, the bitmask is also one byte. The values are entered in the first available rule (1) as **Class Pattern 1** and **Class Priority 1**.

The rest of the traffic (FTP, Web browsing, etc.) will receive default priority 2. On the other side of the network, the modem connected to the computer will also classify outgoing data traffic with default priority 2 because no rule has been programmed.

Note: While the offset value is assumed to be decimal, the patterns and the bitmasks are in hexadecimal format by default.

3.5 Firmware Update Page

This page appears when a firmware update is requested from the **Change Configuration** page, and it shows the status of the current firmware update. The **Firmware Update** page is reloaded automatically every 30 seconds. When the status line shows **Ready: finished correctly**, the wall mount can be restarted, and the new firmware will be loaded.

If the update process fails, an error message will be shown. In this situation, the wall mount can be reset without any risk, but the old firmware will still be present on the wall mount.

4 In-Home AV Network Topology

4.1 Introduction

An *In-Home AV* network is made of an access point (AP) node and several end points (EPs). One and only one access point (AP) can be in an In-Home AV network. However, it is possible that more than one In-Home AV network can coexist together, each of them with its own AP, because each of them is isolated from the others by means of a different network identifier. A modem can be configured as a Fixed AP (i.e. it always will be an AP) or an automatic EP/AP. In case of automatic configuration, the In-Home AV protocol will decide dynamically if the node becomes an EP or an AP. It means, that in a network where no Access Point (AP) has been defined, at least one of the End Points (EPs) will redefine itself as an automatic AP.

Note: It is recommended to configure a Fixed AP. This provides increased stability for future reconfigurations and in multi-network environments.

Note: It is not necessary to have full connectivity between all of the nodes in one network. The network topology will be configured automatically, allowing for the use of repeaters if the connectivity between two nodes falters.

The necessary steps for setting up a basic In-Home AV network are, for each node, as follows:

- Set its **IP address**. It should be a unique **IP** address (e.g. private address like 10.10.1.<last MAC address byte>).
- Select the spectral configuration (**notches** enabled or disabled).
- Set the **Network Identifier**. It should be the same value for all nodes in the network.
- Configure the **Encryption Key**. It should also be the same value for all nodes in the network.
- It is not necessary to configure the **In-Home AV MAC**, since there is only one available network topology in current firmware version. To configure a **Fixed AP** is optional.

4.2 Network Scenarios

In this section the user is presented with a few network scenarios, explaining the application and necessary configuration.

There are two types of an In-Home AV network.


- **Public Network** - This is the default configuration of an In-Home network. If the user does not want to configure its network, the network configuration protocol will configure all nodes automatically. By default, all nodes are EPs and have a public network ID. If the protocol does not detect an AP in the channel, it will select an EP as automatic AP. All EPs will connect directly to the automatic AP if they have direct visibility, or to an EP that will act as a repeater. Then the network will be established.
- **Private Network** - To configure a private network (to ensure data privacy), a network ID must be assigned to all nodes of the network using the configuration tool. It is recommended to configure a node as a fixed AP (for example the node with the video server or Internet access). If the fixed AP is turned off or it is not defined by the user, the network configuration protocol will select an EP to be transformed into an AP (automatic) to configure the network.

4.2.1 Single-Network Scenarios

The following two sections show examples of a single In-Home AV network.


4.2.1.1 Local Area Network using two AV200 powerline Ethernet Wall Mounts

The picture below shows a simple PLC (Powerline) network where two Wall Mounts are used to make a local area connection available in all outlets of the house. This is the simplest case, where no QoS (Quality of Service) configuration is required.



4.2.1.2 Extending the internet connection to an AV200 powerline network


The next picture shows a more advanced PLC (Powerline) network with three *Corinex AV200 Powerline Ethernet Wall Mounts*. This is a common network configuration, where Internet access and digital video are delivered through the same ADSL line. This configuration requires some QoS (Quality of Service) settings to guarantee video quality when the network is carrying large amounts of data from the Internet connection.



Note: Any of these two basic scenarios can be enlarged, adding more adapters, computers and set-top boxes.

4.2.2 Multi-Network Scenarios

A multi-network scenario occurs whenever there are two or more nodes from different In-Home AV networks (different network IDs) that have direct visibility. In this case, a coexistence mechanism that allows a secure form of communication without interference from nodes from different networks is included.



In multi-network scenarios, such as the one depicted in the picture above, there is a new entity, called the QoS controller. The QoS controller's role is to assign channel access to the different networks. The QoS controller acts at the same time as the AP of one of the networks. In the presence of several In-Home networks, the coexistence protocol automatically selects one of the APs as the QoS controller.

31

4.2.2.1 Two networks with no visibility

If two In-Home AV networks are configured, with no direct visibility between any of the nodes belonging to different networks, then these two networks will behave as two independent networks. Both APs will act as QoS controllers.

4.2.2.2 Two networks with direct visibility

Different networks are defined by different network IDs.

If two In-Home AV networks are configured as public networks, the coexistence protocol will act as if there were only one network. The network ID is transmitted by every node to communicate the existence of its network. If a node with a network ID A receives a network ID B, then it knows that there are at least two networks sharing the channel.

For example, one In-Home AV network is configured and running. A second network is configured and starts working after the first network is configured. Then the second network will notify its presence to the first network in some specified access slots, and both networks will automatically be reconfigured and will share the channel. If both networks are configured at the same time, the QoS controller will be selected from all of the present APs.

5 Network Configuration

5.1 Setting an IP Address in your computer


This section explains how to set a static IP in your computer's operating system, in order to connect to the *AV200 Powerline Ethernet Wall Mount* and configure it.

5.1.1 Setting up a static IP in Windows XP


1. Click the **Start** button, open the **Control Panel**. From there, click the **Network Connections** icon and then the **Network Connections** window appears.



2. Select the **Local Area Connection** icon for the applicable adapter (Ethernet adapter or Powerline - usually the first adapter listed). Double-click the **Local Area Connection**.
3. The **Local Area Connection Status** screen will appear. Click the **Properties** button.




4. Select **Internet Protocol (TCP/IP)** and click the **Properties** button.



5. Select **Use the following IP address**. Set the **IP address** manually in the format 10.10.1.X (for example 10.10.1.200) and mask 255.255.0.0 of local TCP/IP settings. The **Default gateway** box can be empty.


33




- Click **OK** button in the TCP/IP Properties window to complete the PC configuration, and click **Close** or the **OK** button to close the Network window.

5.1.2 Setting up a static IP in Windows 2000


- Go to the **network** screen by clicking the **Start** button. Click **Settings** and then **Control Panel**. From there, double-click the **Network** and **Dial-up Connections** icon.




- Select the **Network and Dial-up Connections** icon for the applicable Ethernet adapter (usually it is the first Local Area Connection listed). Do not choose a TCP/IP entry which name mentions DUN, PPPoE, VPN, or AOL. Double click the **Local Area Connection**. The following window will appear.



- Click the **Properties** button to get to the Local Area Connection Properties.



- Select **Internet Protocol (TCP/IP)** and click the **Properties** button.
- Select **Use the following IP address**. Set the **IP address** manually in the format 10.10.1.X (for example 10.10.1.200) and mask 255.255.0.0 of local TCP/IP settings. The **Default gateway** box can be empty.



6. Click **OK** button in the TCP/IP Properties window to complete the PC configuration, and click **Close** or the **OK** button to close the Network window.

5.1.3 Setting up a static IP in Windows 98

1. Go to the **network** screen by clicking the **Start** button. Click **Settings** and then **Control Panel**. From there, double-click the **Network** icon.
2. On the **Configuration tab**, select the **TCP/IP** line for the applicable Ethernet adapter. Do not choose a TCP/IP entry that mention DUN, PPPoE, VPN, or AOL names. If the word TCP/IP appears by itself, select this line. If there is no TCP/IP line listed, please refer to your Ethernet Adapter's User Guide on how to install TCP/IP protocol. Click the **Properties** button.
3. If you do not have DHCP server on the network, then select **Use the following IP address**. Set the **IP address** manually in the format 10.10.1.X (e.g. 10.10.1.200) and mask 255.255.0.0 of local TCP/IP settings and click the **OK button**.
4. Click the **OK** button again. Windows may ask you for the original Windows installation disk or additional files. Supply them by pointing to the correct file location, e.g., D:\win98, D:\win9x, c:\windows\options\cabs, etc. (if "D" is the letter of your CD-ROM drive).
5. Windows may ask you to restart your PC. Click the **Yes** button. If Windows does not ask you to restart, restart your computer anyway.

5.1.4 Setting up a static IP in Linux

1. You have to be logged in as **root** in order to change the IP address in your Linux system.
2. Enter the console if you are using some graphical user interface (KDE, Gnome).
3. To change the IP address to 10.10.1.200, enter the command:

```
ifconfig eth0 inet 10.10.1.200 netmask 255.255.0.0 up
```

and press **Enter**. The previous command take eth0 as the name of the Ethernet interface and may be different on your system. You can check the status of all network interfaces by executing the command **ifconfig** on the console.

```

root@pepcok:-- Shell - Konsole
Session Edit View Bookmarks Settings Help


[root@pepcok root]# ifconfig eth0 inet 10.10.1.200 netmask 255.255.0.0 up
[root@pepcok root]# ifconfig
eth0      Link encap:Ethernet  HWaddr 00:A0:D1:DD:3B:51
          inet addr:10.10.1.200  Bcast:10.255.255.255  Mask:255.255.0.0
          inet6 addr: fe80::2a0:d1ff:fedd:3b51/64  Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:55  errors:0  dropped:0  overruns:0  frame:0
          TX packets:19  errors:0  dropped:0  overruns:0  carrier:0
          collisions:0  txqueuelen:1000
          RX bytes:7095 (6.9 Kb)  TX bytes:1418 (1.3 Kb)
          Interrupt:10  Base address:0xa000

lo        Link encap:Local Loopback
          inet addr:127.0.0.1  Mask:255.0.0.0
          inet6 addr: ::1/128  Scope:Host
          UP LOOPBACK RUNNING  MTU:16436  Metric:1
          RX packets:51  errors:0  dropped:0  overruns:0  frame:0
          TX packets:51  errors:0  dropped:0  overruns:0  carrier:0
          collisions:0  txqueuelen:0
          RX bytes:3379 (3.2 Kb)  TX bytes:3379 (3.2 Kb)

[root@pepcok root]# █
  
```


5.1.5 Setting up a static IP in Mac OS

1. Open the **Network Control Panel** in **System Preferences**.




37

2. Select **Built-in Ethernet** from the pop-up menu.



- Set the **IP address** manually in the format 10.10.1.X (e.g. 10.10.1.200) and **Subnet Mask** 255.255.0.0.



- Click on **Apply Now** and close the **Network** panel, saving your settings.

5.2 Improving network performance

38

The latency of a PLC network is higher than that of an Ethernet network. Most operating systems have a default setting of the network latency based on Ethernet figures. To obtain the maximum performance using TCP traffic (FTP download, for example) the operating system has to be tuned to the new network conditions. For improving the network performance, we provide scripts for Windows and Linux operating systems. The scripts can be found on the enclosed CD, in the folder **scripts**. The scripts will set the TCP window size to 512 kB.

With a Windows PC, simply double-click on the file **tcpwin.reg**, provided on the documentation CD in the „scripts“ folder. You can also run the script using the autorun feature of the CD.

```
Windows Registry Editor Version 5.00
[HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\Tcpip\Parameters]
"TcpWindowSize"=dword:00080000
"GlobalMaxTcpWindowSize"=dword:00080000
"Tcp1323opts"=dword:00000003
```

tcpwin.reg for use with Windows operating systems

With a Linux PC running kernel 2.4 or higher, open the console and execute the command `./tcpwin.sh 512` logged in as `root`.

```

##!/bin/sh
#
# Corinex TCP Window Size Tweak
#
if [ "$#" -eq 0 ]
then
    echo "Usage: $0 <window size in KB>"
    exit
fi
WIND=`expr $1 \* 1024`
echo $WIND > /proc/sys/net/core/rmem_default
echo 8388608 > /proc/sys/net/core/rmem_max
echo $WIND > /proc/sys/net/core/wmem_default
echo 8388608 > /proc/sys/net/core/wmem_max
echo 4096 $WIND 8388608 > /proc/sys/net/ipv4/tcp_rmem

```

tcpwin.sh for use with Linux operating systems

After applying the script, please reboot the system. This applies for both Windows and Linux.

39

5.3 Checking Network Performance

On the **Main** page, under the heading **Available PLC Connections**, there is a list of the MAC addresses of all of the neighboring adapters that have a connection with that adapter. The list also indicates the physical throughput (actual data rate), in terms of both transmission and reception, that the adapter is achieving with each adapter on the network.


Available PLC Connections				
PLC Port	MAC Address	Phy Tx Throughput	Phy Rx Throughput	Bridge State
10	0050C22CF6B8	116 Mbps	114 Mbps	Forwarding
9	0050C22CF6C6	112 Mbps	110 Mbps	Forwarding

5.4 Using PLC Filters

A PLC (Powerline) filter is a low-pass filter that will only allow the 50/60 Hz main voltage through. This filter blocks the Powerline signal.


When to use this filter:

- When you want to isolate a Powerline test network from the rest of the electrical grid, either because you don't want the Powerline signal from the test network to go out and disrupt other adapters, or because you want to isolate this network from the noise, or other traffic, in the rest of the electrical grid. This setup is illustrated in the picture below.



40

- When you want to isolate the electrical noise produced by some household appliance, because this noise falls in the PLC band and disrupts the signal from the adapters. This setup is illustrated in the picture below.



6 Troubleshooting Guide

The *Corinex AV200 Powerline Ethernet Wall Mount* has been designed to be a reliable and easy-to-use network connection device. Please refer to the list below to aid in troubleshooting.

The POWER LED is off.

1. Make sure the wall mount is properly plugged directly into the electrical outlet, and that the outlet has power.
2. Try another outlet.

The Powerline Act LED is off.

1. Make sure the wall mount is plugged directly into the outlet, rather than into a surge suppressor or power strip. The current model of the Powerline AV 200 Ethernet Wall Mount is not designed to function through a surge suppressor.

The Ethernet LED is off.

1. Make sure the wall mount is connected with an Ethernet enabled device with an RJ-45 cable and both devices are powered.

If the trouble persists, please visit www.corinex.com and go to the appropriate section for information on your product. There you will find news, manuals and software updates, as well as frequently asked questions (FAQ).

To avoid personal injury and damage to the system:

1. The principal method to disconnect the device completely from the electrical power network (mains) is to unplug the power cord from the mains socket.
2. Never install the unit in wet areas or next to radiators/heaters.
3. Never use the unit outside.
4. Unplug the unit during severe storms.
5. Never open the equipment enclosure.

If you can't solve your problems using the information sources mentioned above, please send us the problem description via <http://www.corinex.com/web/com.nsf/Doc>. We would like you to give us all possible information about your devices and your network, when contacting us. This includes:

- Types of devices you have, if possible with serial numbers (printed on the safety labels)
- Which of these devices are working incorrectly or don't work at all (indicate the problems)
- If it's possible, send us a scheme of your network topology also with the IP addresses for computers/router/access point, this can speed up the problem estimation. If you use any non-Corinex equipment, please specify what kind. The drawing can be made in any graphics editor, exported to one of the standard graphic formats (JPEG, GIF). Or you can just draw it on paper and scan it
- Specify operating systems used with the devices
- Please send us the firmware version and configuration of these devices. Please see the user guide for detailed instructions on this.