

Corinex Wireless to Powerline Access Point



Declaration of Conformity



Model: **Corinex Wireless to Powerline Access Point**

Manufacturer:

Corinex Communications Corp.
World Trade Center
404-999 Canada Place
Vancouver B.C.
Canada V6C 3E2

Directives which Conformity is Declared:

EMC: 89/336/EWG
LVD: 73/23/EEC
93/68/EEC

Standards which Conformity is Declared:

EN 55022
EN 55024
EN 61000-3-2/A14
EN 61000-3-3
EN 60950

The undersigned hereby declares the above specified equipment conforms to the above directives and standards.

Signature: .....


Printed name: **Peter Sobotka**.....

Place/Date:**2003**.....

Position/Title:**CEO**.....

Declaration of Conformity

For US Market Only



Model: **Corinex Wireless to Powerline Access Point**

Manufacturer:

Corinex Communications Corp.
World Trade Center
404-999 Canada Place
Vancouver B.C.
Canada V6C 3E2

This device complies with Part 15 rules. Operation is subject to the following two conditions:

- 1) this device may no cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules.

User Warning !

Any changes or modification to said product not expressly approved by Corinex could void the user's authority to operate the equipment.

Signature: 

Place/Date: 2003

Printed name: **Peter Sobotka**

Position/Title: **CEO**

This document, as well as the software described in it, is furnished under license and may be used or copied only in accordance with the terms of the license. The content of this document is furnished for informational use only, it is subject to change without notice, and it does not represent a commitment on the part of Corinex Communications Corp.

Corinex Communications Corp. assumes no responsibility or liability for any errors or inaccuracies that may appear in this document.

It is our policy to enhance our products as new technologies, hardware components, software and firmware become available; therefore, the information contained in this document is subject to change without notice.

Some features, functions, and operations described in this document may not be included and sold in certain countries due to government regulations or marketing policies.

The use of the product or its features described in this document may be restricted or regulated by law in some countries. If you are unsure which restrictions or regulations apply, you should consult your regional Corinex office or the authorized reseller.

Published by:
Corinex Communications Corp.
World Trade Center
404-999 Canada Place
Vancouver, B.C.
Canada V6C 3E2
Tel.: +1 604 692 0520
Fax: +1 604 694 0061

Corinex is a registered trademark of Corinex Communications Corp.

Apple, MAC OS X are either registered trademarks or trademarks of Apple Computer, Inc. in the U.S.A. and/or other countries.

Microsoft, MS-DOS, MS, Windows are either registered trademarks or trademarks of Microsoft Corporation in the U.S.A. and/or other countries.

All products or company names mentioned herein may be the trademarks of their respective owners.

Copyright (c) 2001-2003 by Corinex Communications Corp.

Content

Package Content	3
Requirements	4
Installation Overview	4
Step 1: Connecting the Access Point	5
Step 2: Configuring Computers	6
Step 3: Configuring the Access Point	10

Wireless to powerline local area network (LAN) solutions, based on Corinex *Wireless to Powerline Access Point* (AP) products, connect a wireless device to the electrical wires in premises. The electrical wires build the "backbone" for other "wired" or "wireless" devices on the network, which are connected to this backbone by Corinex Powerline adapters or another wireless to powerline access point. Any high-performance *Corinex Wireless to Powerline AP* extends the coverage of your network of electrical wires and provides access to the Internet and corporate or personal information for all mobile devices without expensive additional cabling infrastructure.

The *Corinex Wireless to Powerline Access Point* is a Powerline to wireless LAN Bridge for mixed wireless 802.11b and Powerline network environment. With the built-in 802.11b capability, you can connect your legacy wireless device to the home network by plugging the *Corinex Wireless to Powerline Access Point* into your power plug.

The AP's power jack is a connecting medium to the 14 Mbps digital powerline communication network based on the HomePlug 1.0.1 standard. Plug the *Corinex Wireless to Powerline AP* into an existing powerline network and instantly add full 802.11b-compliant wireless connectivity at up to 11 Mbps. This allows the easiest deployment of wireless HotSpot areas where every power outlet can be used as a powerline network interface to the access point. With *Corinex Wireless to Powerline AP* you have already got the network you need to give the wireless access an entirely new dimension.

Package Content

Package Includes:

By receiving your *Corinex Wireless to Powerline Access Point*, check to be sure that your package contains:


- Corinex Wireless to Powerline Access Point
- Detachable wireless antenna
- AC adapter
- Installation CD-ROM with User Guide
- Quick Installation Guide

Requirements

- IBM Compatible PC or Macintosh computer (needed for initial configuration of the Access Point)
- AC 220/110 V power outlet
- Powerline and/or Wireless connection for each PC
- Windows 98/ME/200/NT/XP, Mac OS X or Linux operating system
- Web browser supporting JavaScript for the AP management

Installation Overview

This Guide will assist you with successful installation and configuration of your *Corinex Wireless to Powerline Access Point* for the first time. It will help you with basic settings, which are covering most of the settings you may need to configure for your Internet connection to be shared through the Powerline medium. However, if you require more sophisticated setup, we advise you to read the *Corinex Wireless to Powerline Access Point User Guide*, enclosed in the Installation CD.



Powerline Bridge for WLANs

The next chapters will explain you how to connect your *Corinex Wireless to Powerline Access Point* in three easy steps.

Step 1: Connecting the Access Point

Locate an optimum location for the Access Point. The best place for the Access Point is usually at the center of your wireless network, with line of sight to all of your mobile stations.

Fix the direction of the antenna. Try to place it in a position which can best cover your wireless network. Plug the supplied AC power adapter to the *Corinex Wireless to Powerline Access Point* and consequently into an AC outlet. **Use only the power adapter supplied with the Access Point. Usage of a different adapter may result in product damage!**

After the *Corinex Wireless to Powerline Access Point* is powered ON, verify LED functionality below:

- The LED on the Powerline side labelled **LINK** should be ON
- The LED on the Wireless side labelled **POWER** should be ON

Note: All other wireless devices must be operating in the infrastructure mode, so that they can communicate with Access Point. If any wireless device is configured in the ad-hoc mode, it WILL NOT be recognized by the Access Point.

Step 2: Configuring Computers

The instructions in this chapter will help you to configure each of your computers to be able to communicate with the *Corinex Wireless to Powerline AP*.

This process differs between powerline connected computers and wireless connected computers and it also depends on operating systems.

A. Using Powerline Connection

We advise you to read and use the Manual of your Powerline Adapter to establish a Powerline connection between *Corinex Wireless to Powerline AP* and Powerline Adapter. Use the Default Powerline (NEK) password "HomePlug", as this is the factory default password setting for the *Corinex Wireless to Powerline AP*. When you are using the *Corinex Setup Tool* to configure your powerline adapter, you can check, whether your Adapter has a powerline connection to the *Corinex Wireless to Powerline AP* by searching in the last window of the *Corinex Setup Tool* for the MAC addresses of the AP. You will find the MAC address of your *Corinex Wireless to Powerline AP* on the label on the bottom of the AP's plastic cover (MAC PLC / SN).



B. Using the Wireless Connection

You may need to reconfigure some wireless settings to ensure all settings match between wireless devices.

Note: Different wireless settings will make successful wireless network connections between wireless adapters impossible.

Default Wireless Interface Settings are as follows:

SSID: **Corinex**
Channel: **11**
WEP: **Disabled**

Note: WEP is disabled by default for an easier installation. For enhanced security, it is recommended that you later (after successful configuration) enable WEP on all wireless devices.

C. TCP/IP Settings

Next you will need to configure your TCP/IP Settings. Computers use IP addresses to communicate with each other across a network or the Internet.

Find out which operating system is running your computer, like Windows 95, 98, Millennium, 2000, XP, Linux or Macintosh OS. We do give you detailed configuration guide to the Windows XP Operating System. Other operating systems have slight differences and we recommend to read the *Corinex Wireless to Powerline AP User Guide* for detailed description how to change TCP/IP settings on your Operating System.

Windows XP TCP/IP Settings

- A. Click the **Start** button, then open the **Control Panel**. From there, click the **Network and Internet Connections** icon and then the **Network Connections** window appears.

- B. Select the Local Area Connection icon for the applicable adapter (wireless adapter, if you are wireless connected or Powerline Adapter if you are powerline connected. It is usually the first adapter listed). Double-click the **Local Area Connection**.
- C. The Local Area Connection Status screen will appear. Click the **Properties** button.



- D. Select **Internet Protocol (TCP/IP)** and click the **Properties** button.



- E. Select **Obtain an IP address automatically** and click the **OK** button. Click the **OK** button again (or the **Close** button if any settings were changed) to complete the computer configuration.



- F. If you do not have DHCP server on the network, then select **Use the following IP address**. Set the **IP address** manually in the shape 192.168.1.X and mask 255.255.255.0 of local TCP/IP settings and click the **OK** button. On the next appearing screen click the **OK** button again.



Step 3: Configuring the Access Point

In this Step, you will configure the *Corinex Wireless to Powerline Access Point*.

- A. Open your web browser. (You can get an error message at this point. Ignore it.) Enter **http://192.168.1.1** in the web browser's **Address** field. Press the **Enter** key and the *Corinex Wireless to Powerline Access Point* web-based configuration utility will start.



A screenshot of a web browser's address bar. The text 'http://192.168.1.1' is entered into the address field. The label 'Address' is visible on the left side of the bar.

- B. Window requiring entering your password will appear. The default password for the configuration utility is **password**. The password is case sensitive. The configuration utility is used to configure both the wireless and powerline aspects of your AP. The wizard contains eight different dialog screen options accessible through the following tabs:

- **Home**

- *Status*
- *Help*

- **IP Address**

- *IP Address Settings*

- **Wireless**

- *Wireless Settings*
- *Security Settings*

- **Powerline**

- *SNMP Agent*
- *NEK Password Setting*
- *Powerline Statistics*
- *Priority Settings*


- **Advanced**

- *MAC Address Filtering*
- *Block Sites*
- *Security Log*


- **Utilities**

- *Restart Access Point*
- *Restore Factory Default*
- *Save/Backup Current Settings*
- *Restore Previous Settings*
- *Firmware Update*
- *System Settings*

- C. The **Status** screen will allow you to review your settings (Firmware Version, Device Name, IP Settings and Wireless Settings).



- D. On the **Login** screen, enter the default password, **password**, in the **Password** field. Then click the **Submit** button. For enhanced security, remember to change this password later through the web-based utility (Utilities / System Settings).



- E. In the **IP Address Settings** page you can configure the IP address used by the web-based utility running on this Access Point. If **DHCP Client** is not enabled, the IP address settings are given here. Otherwise, these settings are supplied by a DHCP server on your network. If you have changed any settings it is necessary to reboot the Access Point for the new settings to take effect.




The screenshot shows the 'IP Setting' page in the Carinex web interface. The page title is 'IP Setting'. Below the title, there is a section for 'IP Address Settings' with a descriptive paragraph: 'On this page you can configure the IP address used by the Web server running on this Access Point. If "DHCP Client" is not enabled, the IP address settings are given here. Otherwise, these settings are supplied by a DHCP server on your network. If you have changed any settings it is necessary to reboot the Access Point for the new settings to take effect.'

The settings are as follows:

- IP Address:** 192, 168, 1, 1
- Subnet Mask:** 255, 255, 255, 0
- Default Gateway:** (empty fields)
- DHCP Client:** Enable

Buttons for 'Apply' and 'Reset' are at the bottom. A 'Connect Status' section with a 'Login' button is on the right. A blue circle with the letter 'E' is in the bottom right corner.

- F. The **Wireless Settings** page allows you to configure the wireless settings. Enter your wireless network's **SSID**, select the **Channel** at which the network broadcasts its wireless signal, name of the AP and fill all the other fields according to your settings requirements. Any new settings will not take effect until the AP is rebooted.



The screenshot shows the 'Wireless Settings' page in the Carinex web interface. The page title is 'Wireless Settings'. Below the title, there is a section for 'Wireless Settings' with a descriptive paragraph: 'You can configuration wireless settings about Channel ID, SSID, etc. Any new settings will not take effect until the access point is rebooted.'

The settings are as follows:

- Regulation Domain:** ETSI
- Wlan Interface:** Enable
- Reject Broadcast probe:** Enable
- Channel ID:** Channel 11
- SSID:** Corinex
- Access Point Name:** Corinex AP
- Basic Rates:** 2 Mb
- Data Rates:** 11 Mb
- Preamble Type:** Long Preamble
- Beacon Interval:** 100
- RTS Threshold:** 2000
- Threshold:** 0

Buttons for 'Apply' and 'Cancel' are at the bottom. A 'Connect Status' section with a 'Login' button is on the right. A blue circle with the letter 'F' is in the bottom right corner.

- G. In the **Security Settings** screen select the **Encryption type**, **Authentication type**, **Radius IP**, **WPA**, **WEP**, etc. Set the **Wired Equivalent Privacy (WEP)** for your wireless network. Select a WEP or other encryption method and a passphrase. Click on **Apply** to make changes.

The screenshot shows the 'Security setting' page in the Corinex web interface. The page is divided into a left sidebar with navigation links, a main content area for settings, and a right sidebar for 'Connect Status'.

Navigation Sidebar:

- Home
- Status
- Help
- IP Address
- IP Address Setting
- Wireless
 - Wireless Settings
 - Security Settings
 - Powerline
- SSID/Channel
- SSID/Password Setting
- Powerline Statistics
- Powerline Settings
- Advanced
 - MAC Address Filtering
 - Block Sites
 - Block URL List
- Utilities
 - Restart Access Point
 - Restore Factory Default
 - Save/Backup Current Setting
 - Restore Previous Setting
 - Firmware Update
 - System Setting

Main Content Area:

Security setting

Wireless Security Settings
You can setting Encryption type and Authentication type ...etc.

Type

Authentication Type: Open System

Encryption Type: None

WEP

WEP Type: Enable 128

Active Key: Key 1

Key 1 (0-hex): [Masked]

Key 2 (0-hex): [Masked]

Key 3 (0-hex): [Masked]

Key 4 (0-hex): [Masked]

802.1x

ReAuthEnabled: False

ReAuthPeriod: 3600

Radius IP

IP Address: 10.1.1.248

Port: 123456

Secret

Secret Key: [Masked]

WPA

Support Station: WPA

Unicast Cipher: TKIP

Key Interval: 3600


PSK (0-HEX): [Masked]

Use passphras: Enable


Buttons: Apply, Cancel

Right Sidebar: Connect Status: Login

H. SNMP Agent - this feature lets you set up SNMP Agent settings.



- I. The **Network Encryption Key** page allows you to configure the Powerline settings. All Corinex Powerline and CableLAN devices are shipped using "HomePlug" as the network encryption key (NEK). The Security dialog screen allows you to change this encryption key, to set your own private NEK and apply it to the *Corinex Wireless to Powerline Access Point*. Click **Apply** button to make changes.



Note: NEK must be between 4 to 24 alphanumeric characters and is case sensitive.

For detailed configuration procedures and functionality of the AP or for installation with other operating system versions, please see the *Corinex Wireless to Powerline User Guide* on the included CD-Rom.